


Instruction for assembling the 3x4m Greenhouse.



Equipment



Connection Element set 1 box.



Set of Frame profiles 3 boxes.



1 sheet is 2,1x6m),



Frame screws (DIN7981-5.5x19) 410 pcs



Self-tapping screws (DIN7504N-4.8x19) 100 pcs



Washers for polycarbonate (DIN9021 M8) 300 pcs



Screws for polycarbonate




Roof skates/edges

Hinges

6 pcs.



Door Handles



1 pcs.







02


Connection **Elements** 54 pcs. Corner 30x30




Instruction for assembling the 3x4m Greenhouse.









Instruction for assembling the 3x4m Greenhouse.

Repeat step 8 and 10 to assemble 2 additional "Frame" panels (3 pcs in total).




www.weisa.lv

Assemble the frame by fastening together the panels and Connection Elements:


- 1) Connect the "S-1" and "D" connection elements to the end wall "FW".
- 2) Connect the "FRAME" panel.

Fasten the panels with frame screws (5.5x19) according to the diagram:




09

Instruction for assembling the 3x4m Greenhouse.



Assemble Door and Window panels:



Carefully flip the panel

and fasten the other side of the panel with screws according to the diagram.



Polycarbonate Layout:

Polycarbonate is installed with the advertisement sticker facing outside.



www.weisa.lv

–1800 mm−- Roof and end wall 2100 1——1800 mm—• 2400 mm 1800 mm 1800 mm →—1800 mm—- 50 mm Roof and end wall ——1800 mm—**→** 2400 mm 1800 mm 1800 mm 1050 mm 1700 mm Side wall and door top E 1050 г 1850 mm 1850 mm 1700 mm 1050 mm 1000 mm Side wall and door bottom 1050 mm 1850 mm 1850 mm 1000 mm


3x4 meters, 4 sheets

- Installation of polycarbonate on the walls and roof is provided with an overlap.
- For convenience, it is recommended to use a board during installation.

Instruction for assembling the 3x4m Greenhouse. Install the upper roof skates and roof edges on top of the **WEIS A** polycarbonate coating using self-tapping screws: www.weisa.lv



Instruction for assembling the Greenhouse 3x4m extension (1.98m).



Equipment



Connection Element set 1 box.



Set of Frame profiles 1 boxes.



Polycarbonate (thickness 4 mm, 1 sheet is 2,1x6m), 1 sheet +2meters.



Frame screws (DIN7981-5.5x19) 190 pcs.



For mounting hinges and Roof skates.

Self-tapping screws (DIN7504N-4.8x19) 18 pcs



Washers for polycarbonat (DIN9021 M8) 60 pcs.



Screws for polycarbonate (DIN7981-4.8x19) 60 pcs.





7)


Connection Elements 24 pcs.












Instruction for assembling the Greenhouse 3x4m extension (1.98m).

Assemble the frame by fastening together the panels and Connection Elements:

- 1) Connect the "S-1" and "D" connection elements to the end wall "FW".
- 2) Connect the "FRAME" panel.

Fasten the panels with frame screws (5.5x19) according to the diagram:



Similarly assemble the rest of the Greenhouse frame.

During montage assistance of a 2nd person is recommended.

